


Pyranometer Insulation Disc

Installation guide for mounting to digital secondary standard Hukseflux pyranometers


Hukseflux offers an optional pyranometer insulation disc. Its purpose is to insulate the pyranometer so the sensor is electrically connected to one ground point only at all times. This installation guide provides instructions how to mount the insulation disc included in this kit to an SR2x and SR3x pyranometer. Please consult the user manual of your pyranometer for more information on pyranometer installation. Using the disc is the user's own decision; it is not the preferred way to ground a sensor.





Unmount pyranometer

The preferred method to unmount the pyranometer (for example for servicing purposes) is to release the pyranometer by using a 4 mm hex key at centre bolt.



An alternative method to release the pyranometer, when the centre hole cannot be reached, is by using a 10 mm spanner.

